



Care & Maintenance

Floating Floor

A floating floor can transform any living space, but it's important to keep it looking its best.

Follow this simple guide to assist in maintaining the natural beauty of your timber floors.

- Sweep or vacuum as often as necessary to remove any loose dirt or grit before it can scratch the floor.
- Use felt protectors under heavy pieces of furniture and chairs.
- Use protective mats at all exterior entrances to minimise dirt entering the area.
- Slightly damp mop only – avoid excessive amounts of water.
- Steam mops must not be used.
- Strictly no boiling water to be used in cleaning.
- Any spills should be wiped off the surface of the floor as soon as they occur.
- Do not use abrasive cleaners, steel wool, or scouring powder on your floor and never wax or polish your floor
- Proper care and maintenance can extend the life of your floor for many years. Over time, a re-coating may be desirable.